

Maintenance instructions

Chameleon PET felt

Not applicable to printed PET felt.



Cleaning

Removing dust and dirt

Is there visible dust or dirt embedded in the material? Gently loosen it using a soft-bristled brush, taking care not to apply too much pressure. Carefully remove the loosened particles with a vacuum cleaner.

Cleaning light stains

First, remove any loose dust and dirt (see above). Blot spilled liquids as quickly as possible to prevent them from penetrating the material. Then, apply a mild cleaning solution or soapy water using a hand spray bottle. Avoid saturating the surface. Allow the material to air dry.

Cleaning stubborn stain

Dampen a lint-free cloth with a mild cleaning solution or a mixture of soap and water. Gently blot the stain from the outside inwards, without rubbing. If necessary, use a clean cloth and repeat the process until no more dirt is visible on the cloth. Then remove any remaining cleaning solution with a dry cloth. Use a clean, damp cloth or sponge to wipe away any residues. Allow the surface to air dry.

Is the stain still visible after these steps? Try using a cleaner suitable for upholstery or carpet fabrics and follow the instructions on the label carefully.

Repair

Removing creases

Creases in PET felt can be smoothed out using an iron. Set the iron to its highest temperature setting. Place a sheet of baking paper over the felt to prevent fibers from sticking to the iron. Slowly and evenly glide the iron over the surface until the creases are gone.